


Materials

- Cutting board
- Scalpel or craft knife
- Ruler
- Double-sided tape
- Scissors for tape



Instructions

1. Cut out all the parts, cutting **only** along the solid blue lines. Be careful with the reel parts — do not remove the inner tabs.
2. Pre-fold the parts along all dotted orange lines.
3. Assemble the reels by folding the internal tabs inward and joining each tab with its corresponding letter.
4. Assemble the playhead (orange pentagon) by folding together and joining each tab with its corresponding letter.
5. Attach the playhead and reels to the front face of the player.
6. Fold up the tape parts and check carefully that the rollers are sitting correctly before fastening. There should be one roller on each face of the tape.
7. Feed the short end of each tape into the gap in the playhead side. Attach rollers in position on the face of the player.
8. Attach the long ends of the tape to the reels, and trim excess material.
9. Bring the front and back half of the player together and fasten tabs to their corresponding letters.

